

Table of Contents

Introduction	2
Safety instructions and important notes	3
Description	6
Operation	8
Cleaning the appliance and removal of limescale deposits	15
Technical specifications	16
Explanation of symbols used on the product, its accessories and packaging	16
Instructions and information about the handling of used packaging	17

Introduction

- The BBW 2010 Baby bottle and food warmer is suitable for both home and in-car use, making it simple to warm up baby bottles or baby food to an ideal temperature within a few minutes both indoors as well as when travelling by car thanks to its car cigarette lighter socket adapter.
- It can warm up all types of baby bottles.
- It can warm up baby foods contained in glass jars.
- Warms up the contents quickly and evenly.
- Automatic shut off at the end of the warming cycle.

Safety instructions and important notes

- Only use the baby bottle warmer in accordance with the instructions included in this user's manual. Not adhering to these instructions may result in the incorrect operation of the bottle warmer or its damage. Keep this user's manual for future use.
- Only use the appliance indoors or in a motor car and do not expose it or its accessories to direct sunlight.
- Keep this appliance and the power cord out of reach of children that are younger than 8 years of age.
- Do not submerge the power cord, plug or the appliance in water or in any other liquid.
- Do not leave the power cord in the vicinity of hot surfaces.
- When the appliance is powered using 230V, connect it only to a grounded power socket. Always check that the plug is properly inserted into the power socket. Before connecting the appliance, check that the voltage specified on the bottom part of the appliance corresponds to the voltage in the local power grid.
- If it is necessary to use an extension cord, check that the power cord is grounded with a nominal value of at least 10 amperes.
- Do not use the appliance if the power plug, power cord or the appliance itself is damaged. If the power cord is damaged, have it replaced at an authorised service centre to avoid a possibly dangerous situation.
- Do not place the appliance on a hot gas or electric stove or a hot oven or in their vicinity.

- Always use the appliance with the appropriate attachment for the type of bottle and baby food, meaning either the bottle tray A② or the food tray A⑥.
- Never turn on the appliance without the necessary amount of water as shown in the Reference warming tables.
- The appliance may be used by children up to 8 years of age and persons with limited physical, sensory or mental abilities or by persons with insufficient experience and knowledge only when under supervision or after they have been instructed about the safe use of the appliance and when they are aware of all risks associated with using the appliance. Cleaning and user maintenance must not be performed by children younger than 8 years of age and that are unsupervised. Children must not play with the bottle warmer.
- Clean the bottle warmer according to the instructions contained in chapter Cleaning the appliance and removal of limescale deposits.
- Do not preheat the appliance.
- Always place a fully assembled baby bottle into the bottle warmer including its screw top and nipple (without the dust cap) and only then pour in the water. Make certain that you pour water into the bottle warmer before turning it on.
- Hot water may cause serious scalding. So be very careful when there is hot water inside the bottle warmer.
- Accessible surfaces of the appliance may heat up during operation.
- Do not move the appliance if it contains hot water.

- As soon as the food or milk reaches the required temperature, remove the bottle or container from the bottle warmer. If you leave the food or milk in the bottle warmer, its temperature will rise.
- Before you start baby a child, always check the temperature of the food.
- Do not touch the bottle warmer if it accidentally falls into the water. Immediately disconnect the power plug from the power socket and do not use the appliance. Contact an authorised service centre.


**Attention:**

Do not leave the bottle warmer without supervision when it is connected to a power socket.

- When not using the appliance, disconnect it from the power socket.
- Before cleaning the appliance, allow it to cool down.
- Follow the instructions for removing limescale deposits to prevent irreparable damage.
- Do not attempt to open or repair the appliance yourself. Have all repairs or adjustments performed at an authorised service centre. By tampering with the appliance you risk voiding your legal rights arising from unsatisfactory performance or quality warranty.
- We recommend saving the original box, packaging material, receipt and responsibility statement of the vendor or warranty card for the duration of warranty. It is appropriate to move the bottle warmer in its original box.


Description

Description of the product



Description of the rear parts of the product

B



① Socket for the 12V car cigarette lighter adapter⑨

② Toggle switch for home use (picture of house), in-car use (picture of a car) and Off

Operation

WARMING UP BABY BOTTLES

a. Home use



Attention:

Never use the bottle warmer without water in the heating tank!

- Stand the bottle warmer on a horizontal and stable surface.
- Place the baby bottle into the bottle tray A② and put it into the heating tank A③.
- For small bottles, use the baby bottle adapter ring A①, that is fitted on to the baby bottle and place it inside the baby bottle warmer adapter A② and put it into the heating tank A③.
- To pour the correct amount of water into the heating tank, use the removable measuring cup A⑥ or a baby bottle with an appropriate measuring scale.
- Adhere to the precise amount of water depending on the amount of food in the baby bottle based on the information in the Reference baby bottle warming table below and use it to find the time necessary for warming up the milk:

Reference baby bottle warming table

Volume of food in the baby bottle	Initial temperature of the liquids in the baby bottle	Amount of water that needs to be poured into the heating tank for home use	Approximate warming up time at home (in minutes)	Amount of water that needs to be poured into the heating tank for in-car use	Approximate warming up time in a motor car (in minutes)
120 ml and less	20 °C	7 ml	2'10	4 ml	6'15
120 - 240 ml	20 °C	8 ml	3'00	5 ml	8'06
240 - 330 ml	20 °C	8 ml	3'40	6 ml	10'15
120 ml and less	4 °C	10 ml	3'00	6 ml	6'55
120 - 240 ml	4 °C	10.5 ml	4'00	6 ml	11'54
240 - 330 ml	4 °C	10.5 ml	4'30	7 ml	13'57

Note:

The time necessary for warming up the milk depends on the amount of milk being heated and its initial temperature, for example room temperature (20 °C) or the temperature after being removed from a refrigerator (5 °C).

- The here mentioned warming times are based on the use of polypropylene bottles (PP). Please note that time intervals for warming up glass bottles may differ.
- Due to the possible consistencies of baby food, the values provided above are only indicative in nature.
- In the event that you find that the baby food is not warmed up sufficiently, restart the warming cycle and next time you may add a little more water into the heating tank A③.
- If on the other hand you find that at the end of the warming cycle that the baby food is too hot, allow the meal to cool down to the required temperature, check it by tapping it against your wrist and next time you can pour a little less water into the heating tank A③.

**Attention:**

If you leave the bottle in the bottle warmer longer than specified in the table, the milk may overheat. If you overheat breast milk, valuable nutrients and vitamins may be lost.

- Never allow water to rise above the neck of the bottle or to spill over the edge of the bottle warmer.
- Check that the switch B② is in the "OFF" position (turned off) and plug the bottle warmer into a power socket using the power cord in socket A⑦.
- Select the warming method by setting switch B② to home warming (picture of a house).
- Press the ON switch A④.
- The indicator light A⑤ signals that the bottle warmer is running.
- The ON switch A④ cannot be used for turning off the appliance. The bottle warmer will automatically turn off at the end of the warming cycle.

**Attention:**

The steam that is released during the warming process is hot. Keep your hands away during the warming process.

- If you wish to turn the bottle warmer off at any time, set the switch B② to the middle OFF position (turned off) and unplug the power cord A⑦ from the power socket.
- At the end of the warming cycle, immediately take the bottle out of the bottle warmer and set the switch B② at the rear of the bottle warmer to the OFF position (turned off). Then, please unplug the appliance from the power socket.
- Shake the baby food or milk after taking it out of the bottle warmer. Check the temperature of the food or milk by dripping a little on your wrist. Carefully dry the bottle before serving the food to a child.

b. In-car use



Attention:

Do not use the bottle warmer in a car while driving, the water inside could reach a high temperature and cause burns. To prevent discharging the car battery, we recommend that the engine is running during the warming process.

- Never use the bottle warmer without water in the heating tank!
- Stand the bottle warmer on a horizontal and stable surface.
- Place the baby bottle into the bottle tray A② and put it into the heating tank A③.
- For small bottles, use the baby bottle adapter ring A①, that is fitted on to the baby bottle and place it inside the baby bottle warmer adapter A② and put it into the heating tank A③.
- To pour the correct amount of water into the heating tank, use the removable measuring cup A⑥ or a baby bottle with an appropriate measuring scale.
- Adhere to the precise amount of water depending on the size of the baby bottle based on the information in the Reference baby bottle warming table above and use it to find the time necessary for warming up the milk.
- Check that the switch is in the middle OFF position (turned off), insert the cigarette lighter adapter A⑨ into the 12V cigarette lighter adapter socket B① and the other end into the your car's cigarette lighter socket.
- Select the warming method by setting switch B② to in-car warming (picture of a car).
- Press the ON switch A④.
- The indicator light A⑤ signals that the bottle warmer is running.
- The ON switch A④ cannot be used for turning off the appliance. The bottle warmer will automatically turn off at the end of the warming cycle.



Attention:

The steam that is released during the warming process is hot. Keep your hands away during the warming process.

- At the end of the warming cycle, immediately take the bottle out of the bottle warmer and set the switch B② at the rear of the bottle warmer to the OFF position (turned off). Then, please unplug the 12V car cigarette lighter adapter A⑨ from the 12V cigarette lighter socket in your car.
- If you wish to turn the bottle warmer off at any time, set the switch B② to the middle OFF position (turned off) and unplug the 12V car cigarette lighter adapter A⑨ from the 12V car cigarette lighter socket.
- Shake the baby food or milk after taking it out of the bottle warmer. Check the temperature of the food or milk by dripping a little on your wrist. Carefully dry the bottle before serving the food to a child.

**Attention:**

Before using the appliance in a motor car, check that the respective 12V car cigarette lighter socket is compatible with the electrical specifications of the appliance!

- Do not use the appliance in a car cigarette lighter socket with a 24V power supply (e.g. in trucks). The product could be irreparably damaged and cause a malfunction of the car's electrical circuits.

**Attention:**

The 12V car cigarette lighter adapter A⑨ is specifically made for this bottle warmer and should never be used with other appliances.

- Before using it, always check that the 12V car cigarette lighter socket is clean and clean it out if necessary.
- If you have just used your car's cigarette lighter socket, leave it open to cool down for 5 minutes and only then use it to connect the bottle warmer.

**Attention:**

Before baby a child, always check that the temperature of the food is not too high! The warming time when using the 12V adapter is different to the warming time at home because the bottle warmer operates at a different voltage, see the Reference warming table.

WARMING UP BABY FOOD

a. Home use



Attention:

Never use the bottle warmer without water in the heating tank!

- Stand the bottle warmer on a horizontal and stable surface.
- Open the jar with the baby food, remove the lid and any labels, then place it into the food tray A⑥ and place this into the heating tank A③.
- To pour the correct amount of water into the heating tank, use the removable measuring cup A⑧ or a container with an appropriate measuring scale.
- Adhere to the precise amount of water depending on the volume of baby food in the jar based on the information in the Reference baby food warming table below and use it to find the necessary warming time:

Reference baby food warming table

Volume of baby food in the jar	Initial temperature of the food inside the jar	Amount of water that needs to be poured into the heating tank for home use	Approximate warming up time at home (in minutes)	Amount of water that needs to be poured into the heating tank for in-car use	Approximate warming up time in a motor car (in minutes)
130 g	20°C	9 ml	2'50	7 ml	6'50
190 g	20°C	11 ml	3'00	11 ml	10'15
130 g	4°C	20 ml	4'30	17 ml	13'44
190 g	4°C	20 ml	5'50	19 ml	16'40

Note:

The warming time depends on the amount of food being heated and its initial temperature, for example room temperature (20°C) or the temperature after being removed from a refrigerator (5°C).

- Due to the large number of possible consistencies of baby food, the values provided above are only indicative in nature.
- While warming up baby food, it is recommended to regularly stir the jar contents to ensure even temperature distribution. Take care not to burn your hands when holding the container.
- In the event that you find that the baby food is not heated sufficiently, restart the warming cycle and next time you may add a little more water into the heating tank A③.

- If on the other hand you find that at the end of the warming cycle that the baby food is too hot, allow the meal to cool down to the required temperature, check it by tapping it against your wrist and next time you can pour a little less water into the heating tank A③.

**Attention:**

If you leave the baby food jar in the bottle warmer longer than specified in the table, the baby food may overheat.

- Never allow water to rise above the neck of the jar or to spill over the edge of the bottle warmer.
- Check that the switch B② is in the "OFF" position (turned off) and plug the bottle warmer into a power socket using the power cord in socket A⑦.
- Select the warming method by setting switch B② to home warming (picture of a house).
- Press the ON switch A④.
- The indicator light A⑤ signals that the bottle warmer is running.
- The ON switch A④ cannot be used for turning off the appliance. The bottle warmer will automatically turn off at the end of the warming cycle.

**Attention:**

The steam that is released during the warming process is hot. Keep your hands away during the warming process.

- If you wish to turn the bottle warmer off at any time, set the switch B② to the middle OFF position (turned off) and unplug the power cord A⑦ from the power socket.
- At the end of the warming cycle, immediately take the jar with the food tray A⑥ out of the bottle warmer and set the switch B② at the rear of the bottle warmer to the OFF position (turned off). Then, please unplug the appliance from the power socket.
- After warming up the food, use a spoon to check that it is not too hot. Carefully dry the jar before serving the food to a child.

b. In-car use**Attention:**

Do not use the bottle warmer in a car while driving, the water inside could reach a high temperature and cause burns. To prevent discharging the car battery, we recommend that the engine is running during the warming process.

- Never use the bottle warmer without water in the heating tank!

- Stand the bottle warmer on a horizontal and stable surface.
- Open the jar with the baby food, remove the lid and any labels, then place it into the food tray A⑥ and place this into the heating tank A③.
- To pour the correct amount of water into the heating tank, use the removable measuring cup A⑧ or a container with an appropriate measuring scale.
- Adhere to the precise amount of water depending on the volume of baby food in the jar based on the information in the Reference baby food warming table and use it to find the necessary warming time.
- Check that the switch is in the middle OFF position (turned off), insert the cigarette lighter adapter A⑨ into the 12V cigarette lighter adapter socket B① and the other end into the your car's cigarette lighter socket.
- Select the warming method by setting switch B② to in-car warming (picture of a car).
- Press the ON switch A④.
- The indicator light A⑤ signals that the bottle warmer is running.
- The ON switch A④ cannot be used for turning off the appliance. The bottle warmer will automatically turn off at the end of the warming cycle.

**Attention:**

The steam that is released during the warming process is hot. Keep your hands away during the warming process.

- At the end of the warming cycle, immediately take the jar with the food tray A⑥ out of the bottle warmer and set the switch B② at the rear of the bottle warmer to the OFF position (turned off). Then, please unplug the 12V car cigarette lighter adapter A⑨ from the 12V cigarette lighter socket in your car.
- If you wish to turn the bottle warmer off at any time, set the switch B② to the middle OFF position (turned off) and unplug the 12V car cigarette lighter adapter A⑨ from the 12V car cigarette lighter socket.
- After warming up the food, use a spoon to check that it is not too hot. Carefully dry the jar before serving the food to a child.

**Attention:**

Before using the appliance in a motor car, check that the respective 12V car cigarette lighter socket is compatible with the electrical specifications of the appliance!

- Do not use the appliance in a car cigarette lighter socket with a 24V power supply (e.g. in trucks). The product could be irreparably damaged and cause a malfunction of the car's electrical circuits.

**Attention:**

The 12 V car cigarette lighter adapter A⑨ is specifically made for this bottle warmer and should never be used with other appliances.

- Before using it, always check that the 12 V car cigarette lighter socket is clean and clean it out if necessary.
- If you have just used your car's cigarette lighter socket, leave it open to cool down for 5 minutes and only then use it to connect the bottle warmer.

**Attention:**

Before baby a child, always check that the temperature of the food is not too high! The warming time when using the 12 V adapter is different to the warming time at home because the bottle warmer operates at a different voltage, see the Reference warming table.

Cleaning the appliance and removal of limescale deposits

Cleaning

- After every use, disconnect the bottle warmer from the power socket and allow it to cool down.
- For hygiene reasons, pour the water out of the bottle warmer.
- Clean the outer and inner side of the bottle warmer using a damp cloth.

**Attention:**

Do not clean the bottle warmer, its parts or its accessories using abrasive products, chemical solvents, cleaning products, alcohol or sharp utensils.

Note:

If you use the bottle warmer to heat baby food, check that there are no spilled baby food remains inside it.

**Attention:**

Never place the bottle warmer directly under running water or submerge the appliance or its parts and accessories in water or other liquids!

- Never wash the bottle warmer in a dishwasher!

- You may clean the baby bottle adapter ring A①, the bottle tray A②, the food tray A⑥ and the measuring cup A⑧ using a sponge or cloth dipped in soapy water or you can wash it in a dishwasher if you place them in the top dishwasher rack.

Removing limescale deposits

- Disconnect the bottle warmer from the power socket and allow it to cool down.
- It is recommended to remove limescale deposits from the bottle warmer every 4 weeks to ensure further effective operation of the appliance.
- Mix 100 ml of white vinegar with 100 ml of hot water and pour this solution into the bottle warmer. Allow this solution to act for approximately 30 minutes in the heating tank A③ and then pour it out.
- Never turn on the bottle warmer while the water and vinegar solution is in the heating tank A③.
- After emptying out the bottle warmer, repeatedly clean the outer and inner side of the bottle warmer using a cloth. In the event that despite this limescale deposits continue to appear, repeat the limescale removal procedure.

Technical specifications

Model number	BBW 2010
Voltage and power input of the appliance	230V ~ 50 Hz, 300 W
Voltage and power input during in-car use	12V DC, 100 W
Protection class against injury by electrical shock	Protection class I.
Operating conditions	Ambient temperature: 7°C to 37°C

Explanation of symbols used on the product, its accessories and packaging



This symbol indicates "Important notice".



This symbol indicates that prior to using the product, the user should read the user's manual.



This symbol indicates that this appliance meets all the basic requirements of EU directives related to it.

 This symbol serves to designate the production lot number.



This symbol indicates that a fee has been paid to an organisation performing recollection and utilisation of the packaging waste.



This symbol indicates the material from which the packaging is made.



This symbol on products or original documents means that used electric or electronic products must not be added to ordinary municipal waste. For proper disposal, renewal and recycling hand over these appliances to determined collection points. Alternatively, in some European Union states or other European countries you may return your appliances to the local retailer when buying an equivalent new appliance. Correct disposal of this product helps save valuable natural resources and prevents potential negative effects on the environment and human health, which could result from improper waste disposal. Ask your local authorities or collection facility for more details. In accordance with national regulations penalties may be imposed for the incorrect disposal of this type of waste.

For business entities in European Union states

If you want to dispose of electric or electronic appliances, ask your retailer or supplier for the necessary information.

Disposal in other countries outside the European Union.

This symbol is valid in the European Union. If you wish to dispose of this product, request the necessary information about the correct disposal method from the local council or from your retailer.



This symbol indicates that the product is approved for in-car use.

Instructions and information about the handling of used packaging

Dispose of used packaging material at a site designated for waste in your municipality.

The Czech language is the original version of the user's manual. Changes to text and technical parameters are reserved.